

**Download and Install Guide for the Zebra® Tag Printer**  
**Operating Systems: Microsoft® Windows® 2000/XP/Vista x32**  
**QuickBooks Point of Sale Versions: 4.0/5.0/6.0/7.0**

**NOTE:** Please make sure you have the latest updates for Point of Sale. (If needed select **Update QBPOS** from the **File** menu.)

**For Windows 2000**

***To download and install the printer drivers:***

1. Download the file Zebra LP2824 to your desktop.
2. Once downloaded, double-click the file on your desktop. The driver files will be automatically extracted to the following location: **C:\Drivers\Zebra LP2824 Tag Printer**. Click **Unzip** to create the directory.
3. Click **OK** and then **Close** on the WinZip® Self-Extractor message.
4. Ensure your printer is turned on and has tags or labels loaded.
5. Plug the printer's USB cable into an available USB port on your computer.
6. The Window's **Found New Hardware Wizard** will open.
  - a. Select **Search for a suitable driver for my device (recommended)** and select **Next**.
  - b. Select **Specify a location** and select **Next**.
  - c. The next window will ask you to select a folder. Select **C:\Drivers\Zebra LP2824 Tag Printer** and select **OK**.
  - d. Select **Next** to install the driver.
  - e. If you receive a hardware installation warning, click **Continue Anyway**.
  - f. When the software installation completes, click **Finish**.

**For Windows XP**

***To download and install the printer drivers:***

1. Download the file Zebra LP2824 to your desktop.
2. Once downloaded, double-click the file on your desktop. The driver files will be automatically extracted to the following location: **C:\Drivers\Zebra LP2824 Tag Printer**. Click **Unzip** to create the directory.
3. Click **OK** and then **Close** on the WinZip® Self-Extractor message.

4. Ensure your printer is turned on and has tags or labels loaded.
5. Plug the printer's USB cable into an available USB port on your computer.
6. The Window's **Found New Hardware Wizard** will open.
  - a. You may be prompted to connect to Windows Update. Select **No, not at this time** and then click **Next**.
  - b. Select **Install from a list or specific location (advanced)** and click **Next**.
  - c. Select **Search for the best drivers in these locations**, and select **Include this location in the search**. Click **Browse**.
  - d. In the resulting window, select **C:\Drivers\Zebra LP2824 Tag Printer** and then click **OK**.
  - e. Click **Next**.
  - f. If you receive a hardware installation warning, click **Continue Anyway**.
  - g. When the software installation completes, click **Finish**.

#### **For Windows Vista**

##### ***To download and install the printer drivers:***

1. Download the file Zebra LP2824 to your desktop.
2. Once downloaded, double-click the file on your desktop. The driver files will be automatically extracted to the following location: **C:\Drivers\Zebra LP2824 Tag Printer**. Click **Unzip** to create the directory.
3. Click **OK** on the WinZip® Self-Extractor message.
4. Ensure your printer is turned on and has tags or labels loaded.
5. Plug the printer's USB cable into an available USB port on your computer.
6. The Window's **Found New Hardware Wizard** will open.
  - a. Select **Locate and install driver software (recommended)**.
  - b. If you see a User Account Control Message, click **Continue**.
  - c. You will see a screen that says to insert the CD that came with your device. Select **I don't have the disc. Show me other options**.
  - d. Select **Browse my computer for driver software (advanced)**.
  - e. The next window will ask you to select a folder that contains the drivers. Browse to and select **C:\Drivers\Zebra LP2824 Tag Printer** and click **OK**.
  - f. Click **Next** to install the software.
  - g. If you see a Windows Security warning message, select **Install this driver software anyway**.

h. When Windows has finished installing the driver software, click **Close**.

**To configure Point of Sale to work with the Zebra Tag Printer:**

1. Start Point of Sale.
2. From the **Edit** menu, choose **Preferences** and then select **Workstation**.
3. Select **Print Options (Documents & Printers** in Version 6.0 and 7.0) from the preferences list.
4. Make the following selections:
  - a. Select the Zebra Tag Printer for each of the documents you want to print with this printer.
  - b. Select an appropriate label template for each of the document types.
  - c. Click **Save**.

***Your tag printer is now ready to use with Point of Sale!***